

HOOD FILTERS & VENTS


FREQUENCY/TIME	1. WEEKLY - (allow 30 mins) Before closing	TOOLS	Latex gloves, cleaning cloth and small ladder
PERSONAL PROTECTIVE EQUIPMENT (PPE)	Latex gloves and mask	CHEMICALS	Fast Foam, All Purpose Cleaner, Cleanshot S/Steel Polish - Ecolab



Remove any obstruction for safety (i.e. poaching pan).
Cover all utensils, pots, fry pans etc with cloth to avoid debris and chemical dripping into them.



Carefully using a small ladder remove each hood filter firmly holding the handles and slowly lift and pull towards you.



Place hood filter one by one in the dish sink. Spray both sides with Fast Foam let it sit for 10 minutes.
Rinse water until clear.
Tilt on an angle to drip water.



Spray and wipe the surfaces with Fast Foam.
Using All Purpose Cleaner and a clean cloth spray the surfaces and wipe clean until streaks disappear.
Polish with Stainless Steel Polish.
Clean any debris underneath if needed.